



The Convex Mirror Shop

INDOOR DELUXE FLUSH FIT MIRROR INSTALLATION GUIDE

1. Measure the distance between the two hole slots on the wall. $6 \frac{11}{16}$ " (170mm)
2. Screw suitable wall screws into the wall making sure they are level and protruding out from the wall approx $\frac{1}{2}$ " (13mm). The screw head must be no bigger than $\frac{1}{4}$ " (6mm) in diameter to fit through the hole.
3. Slot the mirror onto the screws to hang.

