



The Convex Mirror Shop

INSPECTION MIRROR ASSEMBLY GUIDE

- 1. Attach the Telescopic Handle to the Mirror base as per diagram below (if not already assembled).
- 2. Tension the Nyloc Nut as necessary (do not over tighten, as damage may occur to aluminum handle).

NOTE: Base Light Accessory is NOT included. Can be purchased separately.

